

# PRINTER SETUP

PRINTER TYPE = Kube  
PRINTING HEAD TYPE = C80  
INTERFACE..... RS232  
PROGRAM MEMORY TEST.... OK  
DYNAMIC RAM TEST..... OK  
EEPROM TEST..... OK  
CUTTER TEST..... OK  
HEAD VOLTAGE [V] = 24.27  
HEAD TEMPERATURE [°C] = 26  
POWER ON COUNTER = 23  
PAPER PRINTED [cm] = 4480  
CUT COUNTER = 245

RS232 Baud Rate . . . : **9600 bps**  
RS232 Data Length . . : **8 bits/chr**  
RS232 Parity. . . . . : **None**  
RS232 Handshaking . . : **Xon/Xoff**  
Busy Condition . . . . : **RxFull**  
USB Address Number. . : **0**  
Autofeed. . . . . : **CR disabled**  
Print Mode. . . . . : **Normal**  
Chars / inch. . . . . : **A-15 B-20 cpi**  
Speed / Quality . . . . : **High Quality**  
Printing Width. . . . . : **76mm[ 80 PaperW ]**  
Notch Alignment . . . . : **Enabled**  
Notch Threshold . . . . : **3.5 V**  
Notch Distance [mm] . . : **00.0**  
Current . . . . . : **Low**  
Total cut (ESC i) . . . : **Disabled**  
PaperEnd Buffer Clear : **Disabled**  
PowerFail WakeUp Mode.: **LAST PWR State**  
Print Density . . . . . : **0 %**

\* PRINTER RESET \*